



SC Adapter

An optical fibre adapter or uniter is used to mate two connectors together, usually mounted in a distribution panel or wall box. In most cases it is the critical part of the system that aligns the ferrule part of the connectors keeping the fibres in perfect alignment.

Generally there are two types of alignment sleeve within an adapter, phosphor bronze for multi-mode or zirconia (ceramic) for single mode.

<p>Short flange</p>			

Ordering Information

1020	—	22	—	Type	Body Type	Body Material or Color	Dust cap Color	Remark
				<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
				S : SM	SX: Simplex	BL : Blue	BL : Blue	01 : Standard
				M : MM	DX: Duplex	BE : Beige	BE : Beige	02 : Short flange
						GR: Green	GR: Green	
						ME: Metal		

